

1. Turn breaker off for circuit on outlet where fixture is to be installed.

2.Remove mounting bracket from fixture and install to electrical box.

3.Carefully remove packaging from fixture.

4. Adjust wire length to desired mounting height, and tighten strain relief screws to secure.

5. Wire fixture to wires in outlet box. Green wire is for Ground.

6.Install fixture to bracket and tighten screws at the ends of the canopy to secure.

This fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer. Below is a list of recommended dimmers:

Lutron MACL-153M Lutron DVL-153P Lutron SCL-153P Leviton IPL06-10Z Leviton 6674-POW

Due to the inrush current wattage should not exceed 150 watts of product for a 600 watt dimmer.

