



Installation Instructions

Model 39701CLPC

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove X bracket from fixture and install to electrical box
3. Mark 4 holes on outer slots of bracket for hollow wall anchors
4. Remove X bracket from outlet
5. Drill 4 x 1/8" holes and insert hollow wall anchors
6. Reinstall X bracket to outlet and secure bracket to ceiling using 4 screws included into hollow wall anchors
7. Wire fixture to wires in outlet box. Green wire is for Ground.
8. Install fixture to bracket and tighten 4 nuts so that fixture meets the ceiling.
9. Install inner crystal strings A to metal loops on bottom of. It is recommended to use glove included and not touch crystal with bare fingers
10. Install 40 watt G9 xenon bulbs by gently pushing into socket.
(Caution: Xenon bulbs get very hot and may burn you. Always make sure bulbs are off for a minimum 10 minutes before handling)

